



## Clamp holder/receiver

Product code: Clamp01

### Overview

The clamp holder/receiver is used to attach the Skipper XS unit and/or tape end to angular surfaces such as door frames, work surfaces and racking. Simply position the clamp in place and turn the screw to tighten. The clamp holder/receiver can be positioned either horizontally or vertically depending on the desired application.

### Key selling points

- Holds the Skipper XS unit via its connector points or receives any Skipper tape end clip
- Perfect for door frames, worktops and racking

### Key features

- Has an adjustable connector slot which allows it to connect both horizontally and vertically
- Simply adjust the lower clamp up and down the rail to fit the desired surface
- Soft pads to prevent scratching to surfaces

### Product Specifications

<b>Width:</b> 140mm 5.5"	<b>Height:</b> 233mm 8.8"
<b>Depth:</b> 103mm 4.1"	<b>Weight:</b> 205g 7.2oz



Attach the Skipper XS unit to the clamp holder/receiver via one of its connector points.

### Product FAQs

**Q. Does the clamp holder/receiver work with standard Skipper units?**

**A.** The clamp has a connector slot which allows it to receive tape end clips from both the standard Skipper units and Skipper XS units. It cannot be used to hold a standard Skipper unit, but will hold the Skipper XS unit.

**Q. What is the widest surface I can attach the clamp to?**

**A.** The clamp holder/receiver will attach to a surface up to 97mm wide.